





JF1GD70635L 517756

IMPREZA⁰⁵

Owner's Manual.



SUBARU 

Subaru Roadside Assistance

Subaru of America, Inc. provides all owners of Subaru vehicles with coverage in the Subaru Roadside Assistance plan. The coverage term is the same as the Subaru Limited Warranty of three years (36 months) or 36,000 miles, whichever occurs first.

Subaru Roadside Assistance includes the following benefits:

- 24-hour Roadside Assistance, 365 days a year.
- Emergency Towing Service to the nearest authorized Subaru dealer.
- Emergency Roadside Assistance for:



Jump starts



Emergency lockout service



Gasoline (up to 2 gallons)



Flat tire change



Minor fluid replacement

When you find you are in need of Subaru Roadside Assistance services, please call our 24-hour Toll-Free Number:

1-800-261-2155

And provide the following information to your Subaru Roadside Assistance customer service representative:

- Your 17 character Vehicle Identification Number (VIN), and mileage
- Your exact location and type of assistance required.
- Your vehicle's description and license plate number.

continued on back...

SUBARU



SUBARU



The auto-dimming mirror with compass has an anti-glare feature, which automatically reduces glare coming from headlights of vehicles behind you.

AUTO-DIMMING COMPASS MIRROR OPERATING INSTRUCTIONS

Auto-Dimming:

By pressing and releasing the left button, the automatic dimming function is toggled on or off. When the automatic dimming function is on, the auto-dimming indicator light (green) located to the right of the button will illuminate.

Even with the mirror in anti-glare mode, the mirror surface turns bright if the transmission is shifted into reverse. This is to insure good rearward visibility during reversing.

Do not cover the photosensors located to the right of the compass display and along the bottom of the mirror on the opposite surface facing the windshield.

Compass Display Options:

By pressing and releasing the right button, the compass display is toggled on or off. When the compass is on, an illuminated compass reading will appear in the lower part of the mirror.

Compass Zone Adjustment:

1. The zone setting is factory preset to Zone 8. Refer to the "Compass Calibration Zone" map, on the other side of card, to verify the correct compass zone setting for your geographical location.

Place this pamphlet in the
Glove box for future reference.

Form 210361

Revision 2-13-03